

**Key Blanks**

# Classic Auto Truck

Model Years 1940 - 1980



The  to your success



A member of the Kaba Group  
[www.kaba-ilco.com](http://www.kaba-ilco.com)

## HOW TO USE THE AUTO/TRUCK KEY BLANK REFERENCE

- Two indexes are provided; the MANUFACTURER INDEX and the MODEL INDEX. Both indexes are in alphabetical order. The Manufacturer Index references brands like Toyota, Dodge and BMW. The model index lists models like the Camry (Toyota), Ram (Dodge) and 3 Series (BMW). Both indexes tell the user on what page the reference information will be found.
- The BODY of the Reference explains Manufacturer, Model, Years, Lock Applications and Code Series. Lock application terms include ignition, trunk, glove box (GB), valet (operates ignition and door only), and all (single key system, often referred to as a master key). The Ilco/EZ number is the key number. A [P] indicates the key is available with a plastic head.

By learning to use this reference, you can reduce the confusion over which key blank to use in an automobile or truck. **Recognize that there will be exceptions to what is considered standard. Before cutting a replacement key, always compare the key blank to be cut with the original key.**

**IMPORTANT: Before ordering key blanks for your key boards, reference the Notes Column to see if the key blank is a High Security Key and requires a special key machine. Be certain you have the key machine to cut the key before ordering the key blanks.**

MANUFACTURER	PAGE	MANUFACTURER	PAGE
Alfa Romeo	4	Kenworth	9
American Motors (AMC)	4	Lamborghini	9
Audi	4	Lincoln	9
BMW	4	MG	9
Brockway Truck	4	Mack Truck	9
Buick	4-5	Mazda	9
Cadillac	5	Mercedes Benz	9
Chevrolet	5	Mercury	9-10
Chrysler	5	Nash	10
Datsun	5-6	Navistar-International	10
DeSoto	6	Oldsmobile	10
Dodge	6	Packard	10
Edsel	6	Peterbilt	10
Ferrari	6	Peugeot	10
Fiat	6	Plymouth	10
Ford	6-7	Pontiac	10-11
Freightliner	7	Porsche	11
GM	7-8	Renault	11
GMC	8	Rolls Royce	11
Hino Truck	8	Saab	11
Honda	8	Sterling	11
Hudson	8	Studebaker	11
Imperial	8	Subaru	11
International	8	Toyota	11-12
Iveco Truck	8	Triumph	12
Jaguar	8	Volkswagen	12
Jeep	8	Volvo	12
Kaiser-Frazer	8		

This book is provided as a service and is intended for reference only. Kaba Ilco Corp. disclaims liability for any damage or action resulting from the use of this information.

MODEL	MAKE	PAGE	MODEL	MAKE	PAGE
3 Series	BMW	4	Crown	Toyota	12
5 Series	BMW	4	Crown Victoria	Ford	6
6 Series	BMW	4	Dakota Trucks	Dodge	6
7 Series	BMW	4	Dasher	Volkswagen	12
99	Saab	11	Econoline Van	Ford	7
100 Series	Audi	4	F-150 Series	Ford	7
240 Series DL	Volvo	12	F-250 Series	Ford	7
240 Series GL	Volvo	12	F-350 Series	Ford	7
280ZX	Datsun (Nissan)	5	Fairlane	Ford	7
300ZX	Datsun (Nissan)	5	Falcon	Ford	7
411	Volkswagen	12	Fiesta	Ford	7
412	Volkswagen	12	Fox	Audi	4
504	Peugeot	10	Golf	Volkswagen	12
505	Peugeot	10	Gordini	Renault	11
600	Honda	8	Graduate	Alfa Romeo	4
604	Peugeot	10	Grand Marquis	Mercury	10
900	Saab	11	Grand Wagon	Jeep	8
924	Porsche	11	GT6	Triumph	12
928 w/alarm	Porsche	11	GTI	Volkswagen	12
928 w/o alarm	Porsche	11	Land Cruiser	Toyota	12
944	Porsche	11	Mark Series	Lincoln	9
1600	BMW	4	Mustang	Ford	7
2002	BMW	4	Opel	Buick	8
3500S	Sterling	11	Pantera	Packard	10
4000	Audi	4	Prelude	Honda	8
5000	Audi	4	R17	Renault	11
6000	Ford	6	R5 (Le Car)	Renault	11
9000	Ford	6	Rabbit	Volkswagen	12
Alfetta	Alfa Romeo	4	Ram Trucks	Dodge	6
B210	Datsun (Nissan)	5	Ranger Pickup	Ford	7
"Bavaria, 3.0CS"	BMW	4	RX4	Mazda	9
Beetle	Volkswagen	12	SC	Jaguar	8
Bus	Volkswagen	12	Scirocco	Volkswagen	12
Capri	Mercury	10	Sovereign	Jaguar	8
Celica	Toyota	11	Spider	Alfa Romeo	4
CF7000	Ford	6	Spitfire	Triumph	12
Chevrolet Luv	Chevrolet	5	Stag	Triumph	12
Civic	Honda	8	Sterling	Sterling	11
CJ5	Jeep	8	Strada	Fiat	6
Club Wagon	Ford	7	Thunderbird	Ford	7
Colt	Dodge	6	TR6	Triumph	12
Comanche	Jeep	8	Transfer Heavy Trucks	Ford	7
Contach	Lamborghini	9	Vanden Plas	Jaguar	8
Continental	Lincoln	9	Vista	Dodge	6
Corolla	Toyota	11	Wrangler	Jeep	8
Corona	Toyota	11	XJ12	Jaguar	8
Cosmo	Mazda	9	XJ6	Jaguar	8
Cougar	Mercury	10	XJS	Jaguar	8
Coupe	Honda	8			
Courier P/U	Ford	7			

**4 ALFA-ROME0 - CADILLAC**

MODEL	YEARS	LOCK APPLICATIONS	ILCO/EZ [PLASTIC]	SUBSTITUTES	
<b>ALFA ROMEO</b>					
Alfetta	1976-80	Ignition	X109-FT43	F44, SP9	
		Door/Trunk	X64-SP6	—	
			X78-SP8	—	
			X79-SP7	—	
Graduate	1970-94	Door/Trunk		—	
	1970-94	Door/Trunk	F91C	—	
	1970-94	Door/Trunk	F91C8	—	
	1970-80	Ignition	X109-FT43	F44, SP9	
Spider	1970-94	Door/Trunk	F91C2	—	
	1970-94	Door/Trunk	F91C	—	
	1970-94	Door/Trunk	F91C8	—	
	1970-80	Ignition	X109-FT43	F44, SP9	
All Models	1970-75	Ignition	X109-FT43	SP9	
	1966-69	Ignition	FTA2	—	
		1966-75	Door/Trunk	F91C	—
				F91C2	—
				F91CR	—
F91C8	—				
<b>AMERICAN MOTORS (AMC)</b>					
All Models	1970-82	Ignition	1970AM-RA4	S1970AM/RA3	
		Door/Trunk	S1970AM-RA3	1970AM/RA4	
	1957-69	Ignition/Door	H1098NR-RA2	1098NR/RA1	
		Trunk/GB	1098NR-RA1	H1098NR/RA2	
<b>AUDI</b>					
4000, 5000 Sedan Wagon	1978-84	All	X88-PA8 (-P)		
		Valet	X9-73VB (-P)		
100 Series	1973-77	Ignition/Door	PA6	—	
		Trunk/GB	PA5	—	
Fox	1973-77	Ignition/Door	X9-73VB	X203/V37, X88/PA8	
		Trunk/GB	PA5	—	
<b>BMW</b>					
6 Series, 7 Series	1978-84	All	X59-BMW2 (-P)		
		Valet	HF40		
3 Series, 5 Series	1975-84	All	X59-BMW2 (-P)		
5 Series	1975-84	Valet	HF40		
1600 2002	1968-75	Ignition/Door	BMW1	—	
			HF18	—	
		Trunk/GB	WT3	—	
			63Y	—	
Bavaria, 3.0CS	1970-75	All	PE1	—	
<b>BROCKWAY TRUCK</b>					
	1966-02	All	1098M-B1	1098GX/B52	
			01122A-Y12		
			01122AR-Y14	X1199AR/Y133	
			L1054B-IN8	01122/Y11	
<b>BUICK - SEE GM FOR ADDITIONAL REFERENCES</b>					
Misc Models	1980	Ignition	P1098C-B50		
		Door/Trunk/GB	S1098D-B51		
	1979	Ignition/Door	P1098A-B48 (-P,-PC)		
		Trunk/GB	S1098B-B49 (-P,-PC)		
	1978	Ignition	P1098J-B46		
		Door/Trunk/GB	S1098K-B47		
	1977	Ignition	P1098E-B44 (-P,-PC)		
		Door/Trunk/GB	S1098H-B45 (-P,-PC)		
	1976	Ignition	P1098C-B50		
		Door/Trunk/GB	S1098D-B51		
	1971	Ignition/Door	P1098A-B48 (-P,-PC)		
		Trunk/GB	S1098B-B49 (-P,-PC)		
<b>CADILLAC - SEE GM FOR ADDITIONAL REFERENCES</b>					
Misc Models	1980	Ignition	P1098C-B50		
		Door/Trunk/GB	S1098D-B51		
	1979	Ignition/Door	P1098A-B48 (-P,-PC)		
		Trunk/GB	S1098B-B49 (-P,-PC)		
	1978	Ignition	P1098J-B46		
Door/Trunk/GB		S1098K-B47			

MODEL	YEARS	LOCK APPLICATIONS	ILCO/EZ [PLASTIC]	SUBSTITUTES
Misc. Models con't	1977	Ignition	P1098E-B44 (-P,-PC)	
		Door/Trunk/GB	S1098H-B45 (-P,-PC)	
	1976	Ignition	P1098C-B50	
		Door/Trunk/GB	S1098D-B51	
	1971	Ignition/Door	P1098A-B48 (-P,-PC)	
Trunk/GB		S1098B-B49 (-P,-PC)		
<b>CHEVROLET - SEE GM FOR ADDITIONAL REFERENCES</b>				
Chevrolet Luv	1972-80	All	P1098V-LUV2	T61F
Misc Models	1980	Ignition	P1098C-B50	
		Door/Trunk/GB	S1098D-B51	
	1979	Ignition/Door	P1098A-B48 (-P,-PC)	
		Trunk/GB	S1098B-B49 (-P,-PC)	
	1978	Ignition	P1098J-B46	
		Door/Trunk/GB	S1098K-B47	
	1977	Ignition	P1098E-B44 (-P,-PC)	
		Door/Trunk/GB	S1098H-B45 (-P,-PC)	
	1976	Ignition	P1098C-B50	
		Door/Trunk/GB	S1098D-B51	
	1971	Ignition/Door	P1098A-B48 (-P,-PC)	
Trunk/GB		S1098B-B49 (-P,-PC)		
<b>CHRYSLER</b>				
All Models	1968-85	Ignition/Door	P1770U-Y152 (-PC)	—
		Trunk/GB	S1770U-Y149	—
	1968	Ignition	1768CH	—
		Trunk/GB	S1768CH	—
	1967	Ignition/Door	1767CH	—
		Trunk/GB	S1767CH	—
	1966	Ignition/Door	1764P	—
		Trunk/GB	1766S	—
	1964-65	Ignition/Door	1764P	—
		Trunk/GB	1764S	—
	1960-63	Ignition/Door	1705K	—
		Trunk/GB	D1759L	—
	1959	Ignition/Door	1703K	—
		Trunk/GB	D1759L	—
	1957-58	Ignition/Door	1703K	—
		Trunk/GB	1701G	—
	1956	Ignition/Door	X1199J	—
		Trunk/GB	XO1199G	—
	1953-55	Ignition/Door	X1199G	—
		Trunk/GB	XO1199G	—
	1952	Ignition/Door	X1199G	—
		Trunk	XO1199G	—
		GB	1098XL-B4	—
	1951	Ignition/Door	X1199B	—
			X1199G	—
		Trunk	X1199B	—
			XO1199G	—
1949-50	Ignition/Door	X1199G	—	
	Trunk	XO1199G	—	
1940-48	GB	1098XL-B4	—	
	Ignition/Door	X1199B	—	
	Trunk	X1199B	—	
		GB	1098XL-B4	—
<b>DATSUN (NISSAN)</b>				
300ZX, 280ZX	1979-83	All	X115-DA23 (-P)	
B210	1974-80	All	X6-62DT	
	1974-80	All	X7-62DU	
All Models	Pre 1970	All	DT13	—
			DT14	—
			DT15	—
			DT16	—
				—
	1970-73	Ignition	X1-MZ12	—
			X6-62DT	—
			X7-62DU	X10/62DV

**6 DATSUN/NISSAN - FORD**

MODEL	YEARS	LOCK APPLICATIONS	ILCO/EZ [PLASTIC]	SUBSTITUTES
All models con't		Door/Trunk	X6-62DT	—
			X7-62DU	X10/62DV
	1974-75	All	X6-62DT	—
			X7-62DU	X10/62DV
<b>DESOTO</b>				
All Models	1960-61	Ignition/Door	1704K	—
		Trunk/GB	D1759L	—
	1959	Ignition/Door	1702KL	—
		Trunk/GB	D1759L	—
	1957-58	Ignition/Door	1702K	—
		Trunk/GB	1701G	—
1940-56	See Chrysler			
<b>DODGE</b>				
Colt	1970-86	All	X54-DC1 (-P)	X121/DC3
Vans (Full Size)	1970-86	Ignition/Door	P1170U-Y152 (-PC)	—
	1970-86	GB	S1770U-Y149	—
Vista	1970-86	All	X54-DC1 (-P)	X121/DC3
Ram & Dakota Trucks	1968-85	Ignition/Door	P1770U-Y152 (-PC)	—
		GB	S1770U-Y149	—
All Models	1968-85	Ignition/Door/Hatch	P1770U-Y152 (-PC)	—
		Trunk/GB	S1770U-Y149	—
	1968	Ignition/Door	1768CH	—
		Trunk/GB	S1768CH	—
	1967	Ignition/Door	1767CH-Y146	—
		Trunk/GB	S1767CH-Y138	—
	1966	Ignition/Door	1764P	—
		Trunk/GB	1766S	—
	1964-65	Ignition/Door	1764P	—
		Trunk/GB	1764S	—
	1960-63	Ignition/Door	S1707K	—
		Trunk/GB	DF1759L	—
	1959	Ignition/Door	X1199J	—
		Trunk/GB	1759P	—
	1957-58	Ignition/Door	X1199J	—
Trunk/GB		1701G	—	
1940-56	See Chrysler			
<b>EDSEL</b>				
All Models	1959-60	Ignition/Door	1127DP-H27	—
		Trunk/GB	1127ES-H26	—
	1958	Ignition/Door	1127P	—
		Trunk/GB	1127N	—
<b>FERRARI</b>				
Many models	1968-95	Ignition	H61VR	—
			X152-FT46	—
	1968-95	Door/Trunk	FT37	—
			FT38	—
			F91C2	—
			F91C	—
			F91CR	—
			F91C8	—
<b>FIAT</b>				
Strada	1979-80	All	X109-FT43	
All Models	1967-83	Ignition	X109-FT43	SP9
			FT6R	X1/MZ12
			R63SP	—
			63SP	—
		Door/Trunk	F91C	—
			F9/1C2	—
			F91CR	—
			F91C8	—
			FT37	—
			FT38	—
<b>FORD</b>				
Crown Victoria	1967-80	Ignition/Door	1167FD-H51 (-PC)	1181FD/H53
		Trunk/GB	S1167FD-H50 (-PC)	S1181FD/H52
6000,9000,CF7000	1967-85	Ignition	1167FD-H51 (-PC)	1181FD/H53
		Door/GB	S1167FD-H50 (-PC)	S1181FD/H52

MODEL	YEARS	LOCK APPLICATIONS	ILCO/EZ [PLASTIC]	SUBSTITUTES
Transfer Heavy Trucks	1967-85	Ignition/Door	1167FD-H51 (-PC)	1181FD/H53
		GB	S1167FD-H50 (-PC)	S1181FD/H52
Club Wagon	1967-92	Ignition	1167FD-H51 (-PC)	1181FD/H53
		Door/GB	S1167FD-H50 (-PC)	S1181FD/H52
Econoline Van	1967-92	Ignition	1167FD-H51 (-PC)	1181FD/H53
		Door/GB	S1167FD-H50 (-PC)	S1181FD/H52
F-150 Series	1967-92	Ignition	1167FD-H51 (-PC)	1181FD/H53
		Door/GB	S1167FD-H50 (-PC)	S1181FD/H52
F-250 Series	1967-92	Ignition	1167FD-H51 (-PC)	1181FD/H53
		Door/GB	S1167FD-H50 (-PC)	S1181FD/H52
F-350 Series	1967-92	Ignition	1167FD-H51 (-PC)	1181FD/H53
		Door/GB	S1167FD-H50 (-PC)	S1181FD/H52
Ranger Pickup	1967-92	Ignition	1167FD-H51 (-PC)	1181FD/H53
		Door/GB	S1167FD-H50 (-PC)	S1181FD/H52
Vans	1967-92	Ignition	1167FD-H51 (-PC)	1181FD/H53
		Door/GB	S1167FD-H50 (-PC)	S1181FD/H52
Models other than referenced below or next page	1967-75	Ignition/Door	1167FD-H51	1127ME
		Trunk/GB	S1167FD-H50	S1127ME
	1965-66	Ignition/Door	1127FD	—
		Trunk/GB	S1127FD	—
	1959-64	Ignition/Door	1127DP-H27	—
		Trunk/GB	1127ES-H26	—
	1952-58	Ignition/Door	1127D	—
		Trunk/GB	1127ES-H26	—
	1940-51	Ignition/Door	1125H-H5	—
			1125G	—
Falcon	1959-66	Ignition/Door	1127FL	—
		Trunk/GB	S1127FL	—
Fairlane	1962-66	Ignition/Door	1127FR	—
		Trunk/GB	S1127FR	—
Fiesta	1979-80	All	X86FC7(-P)	—
			X20-FC2	—
Mustang	1967-93	Ignition	1167FD-H51 (-PC)	1181FS/H53
		Door/Trunk/GB	S1167FD-H50 (-PC)	S1181FD/H52
	1965-66	Ignition/Door	1127MU	—
		Trunk/GB	S1127MU	—
Thunderbird	1970-84	Ignition	1167FD-H51 (-PC)	1181FD/H53
		Door/Truck	S1167FD-H50 (-PC)	S1181FD/H52
	1965-70	Ignition/Door	1127TB	—
		Trunk/GB	S1127YB	—
	1961-64	Ignition/Door	1127DP-H27	—
		Trunk/GB	1127ES-H26	—
	1955-60	Ignition/Door	1127D	—
		Trunk/GB	1127ES-H26	—
Courier P/U	1974-81	All	X4-MZ4	MZ10
			X5-MZ5	
	1970-73	All	X36-MZ11	—
<b>FREIGHTLINER</b>				
Misc Models	1978-93	Ignition/Door	1098M-B1	
			01122A-Y12	
			1041T-CG16	
<b>GM (BUICK, CADILLAC, CHEVROLET, GMC, OLDSMOBILE, PONTIAC)</b>				
Most Models	1974, 1978	Ignition/Door	P1098J-B46	—
		Trunk/GB	S1098K-B47	—
	1973, 1977, 1981	Ignition/Door	P1098E-B44 (-P,-PC)	P1098EV/B77
		Trunk/Door	S1098H-B45 (-P,-PC)	S1098WH/B79
	1972, 1976, 1980	Ignition/Door	P1098C-B50	—
		Trunk/GB	S1098D-B51	—
	1971, 1975, 1979	Ignition/Door	P1098A-B48 (-P,-PC)	—
		Trunk/GB	S1098B-B49 (-P,-PC)	—
	1970	Ignition/Door	P1098J-B46	—
		Trunk/GB	S1098K-B47	—
	1969	Ignition/Door	P1098E-B44 (-P,-PC)	P1098EV/B77
		Trunk/GB	S1098H-B45 (-P,-PC)	S1098WH/B79
	1968	Ignition/Door	L3098C	—
		Trunk	O1098D	S1098D/B51
1967	Ignition/Door	H1098A	P1098A/B48	
	Trunk/GB	O1098B	S1098B/B49	

**8 GM - KAISER/FRAIZER**

MODEL	YEARS	LOCK APPLICATIONS	ILCO/EZ [PLASTIC]	SUBSTITUTES
Most models con't	1940-66	Ignition/Door	H1098LA-B10	—
		Trunk/GB	O1098LA-B11	—
Buick Opel	1966-75	All	OP11	—
			O79JB	—
			O79JD	—
			O79JE	—
			HF21	—
<b>GMC - SEE GM FOR ADDITIONAL REFERENCES</b>				
<b>HINO TRUCK</b>				
All Models	1975-89	All	X137-TR33 (-P,-PC)	
<b>HONDA</b>				
Prelude	1979-81	All	X71-HD70U (-P)	HD70, HD71
All Models	1970-75	Ignition	X51-AA2	—
Civic	1976-81	All	X71-HD70U (-P)	HD70, HD71
	1973-76	Door/Trunk	X44-HO44	—
Coupe, 600	1971-75	Door/Trunk	X38-HO41	—
	1971-72	Door/Trunk	X19-HD40	—
	1980-71	Door/Trunk	HD23	—
			HD29	—
			HD30	—
			HD31	—
			HD32	—
HD33	—			
HD35	—			
<b>HUDSON</b>				
All Models	1940-57	Ignition/Door	H1098X-B24	1098M/B1
		Trunk/GB	1098X	1098M/B1
<b>IMPERIAL</b>				
All Models	1968-75	Ignition/Door	P1770U-Y152	—
		Trunk/GB	S1770U-Y149	—
	1967	Ignition/Door	1767CH	—
		Trunk/GB	S1767CH	—
	1964-66	Ignition/Door	1764P	—
		Trunk/GB	1764S	—
	1960-63	Ignition/Door	1705K	—
		Trunk/GB	D1759L	—
	1959	Ignition/Door	1703K	—
		Trunk/GB	D1759L	—
	1955-58	Ignition/Door	1703L	—
		Trunk/GB	1701G	—
<b>INTERNATIONAL</b>				
All Models	1940-75	Ignition	1098DB-B5	H1098DB/H16
		Door	1098DB-B5	H1098DB/H16
			1098M-B1	H1098M/B2
		GB	H1098X-B24	1098X
<b>IVECO TRUCK</b>				
All	1980-82	Ignition	X157-LF17	
		Doors	FT37	
<b>JAGUAR</b>				
XJ6, XJ12, Vanden Plas XJS, SC	1979-87	Door/Trunk	BL6	
	1976-85	Ignition	FT6R	X1/MZ12
Doors		WB3		
Trunk		X86-FC7 (-P)	X20/FC2	
XJ6, XJ12	1976-78	Door/Trunk	BL6	X20/FC2
			X86-FC7 (-P)	
Sovereign, Van	1973-87	Ignition	FT6R	X1/MZ12
	1973-75	Door/Trunk	62FS	
		Door/Trunk	62FT	
<b>JEEP</b>				
Grand Wagon, Wrangler, Comanche, CJ5	1974-84	Ignition	1970AM-RA4	
		Door/Tailgate	S1970AM-RA3	
All Models	1947-75	Ignition	1098DB-B5	H1098DB/H16
<b>KAISER-FRAZER</b>				
All Models	1947-51	Ignition/Door	O1122A-Y12	—
		Trunk/GB	O1122AR-Y14	—
	1946-47	Ignition/Door	O1122-Y11	—
		Trunk/GB	O1122R-Y13	—



MODEL	YEARS	LOCK APPLICATIONS	ILCO/EZ [PLASTIC]	SUBSTITUTES	
<b>KENWORTH</b>					
All US Models	1978-93	All	1098DB-B5	H1098DB/B16	
<b>LAMBORGHINI</b>					
Contach	1970-87	Ignition	X109-FT43	—	
		Door/Trunk	FT37	—	
			FT38	—	
			F91C	—	
			F91C2 F91C8	—	
<b>LINCOLN</b>					
Continental	1966-80	Ignition/Door	1167FD-H51 (-PC)	1170LN	
		Trunk/GB	S1167FD-H50 (-PC)	S1170LN	
Mark Series	1967-80	Ignition/Door	1167FD-H51 (-PC)	1170LN	
		Trunk/GB	S1167FD-H50 (-PC)	S1170LN	
All Models	1970-75	Ignition/Door	1170LN	1167FD/H51	
		Trunk/GB	S1170LN	S1167FD/H50	
	1966-69	Ignition/Door	1766LN	1167FD/H51	
		Trunk/GB	S1766LN	S1167FD/H50	
	1959-65	Ignition/Door	1761LP	1761MP	
		Trunk/GB	1761S	1761MS	
	1958	Ignition/Door	1127T	—	
		Trunk/GB	1127L	—	
	1957	Ignition/Door	1127D	—	
		Trunk/GB	1127L	—	
1940-56	See Ford				
<b>MG</b>					
All Models	1978-81	Ignition	X29-VO73		
		Door/Trunk	62FS		
			62FT		
	1970-75	Ignition	X51-AA2	—	
		Door/Trunk	MG1	—	
			62FS	—	
			62FT	—	
	late 60's	Various	62DG	—	
			62DP	—	
			62FS	—	
			RE61XR	—	
	<b>MACK TRUCK</b>				
	US Designed	1971-86	Ignition/Door	1098M-B1	1098GM
<b>MAZDA</b>					
Cosmo	1976-79	All	X60-MZ14	—	
RX4	1974-82	All	X26-MZ9 (-P)	—	
			X27-MZ10		
Misc Models	1970-76	Ignition	X1-MZ12	FT6R	
	1970-82	Door/Trunk	X26-MZ9 (-P)	—	
	1970-82	Door/Trunk	X27-MZ10	—	
<b>MERCEDES BENZ</b>					
All Models	1973-79	All	MB18	—	
			MB15	—	
			MB16	—	
	1970-72		MB17	—	
			MB59	—	
	1965-69	Ignition Door/Trunk	63C	—	
			YM1	—	
			YM4	—	
			63TV	—	
			YM3	—	
			HF4	—	
			HF9	—	
			HF14	—	
			HF15	—	
			HF16	—	
<b>MERCURY</b>					
U.S. Designed	1965-75	Ignition/Door	1127ME	1167FD/H51	
		Trunk/GB	S1127ME	S1167FDH50	
	1959-64	Ignition/Door	1761MP 1761MS	1761LP 1761LS	

# 10 MERCURY - PONTIAC

MODEL	YEARS	LOCK APPLICATIONS	ILCO/EZ [PLASTIC]	SUBSTITUTES
U. S. Designed con't	1940-58	See Ford		
Capri	1975-78	All	X86-FC7	X20/FC2
	1971-74	Ignition	X86-FC7	X20/FC2
		Door/Trunk	X21-YS1	—
			X22-YS2	—
	1970	Ignition	KL2	—
Door/Trunk		FT37	—	
		FT38	—	
Cougar	1967-82	Ignition/Door	1167FD-H51 (-PC)	1170LN
		Trunk/GB	S1167FD-H50 (-PC)	S1181FD/H52
Grand Marquis	1967-80	Ignition/Door	1167FD-H51 (-PC)	1170LN
	1967-80	Trunk/GB	S1167FD-H50 (-PC)	S1181FD/H52
<b>NASH</b>				
All Models	1949-57	Ignition/Door	H1098NR-RA2	1098NR/RA1
		Trunk/GB	1098NR-RA1	H1098NR/RA2
	1940-48	Ignition/Door	H1098NR-RA2	1098NR/RA2
		Trunk/GB	O1098LA-B11	—
<b>NAVISTAR-INTERNATIONAL</b>				
All	1976-04	Ignition	1970AM-RA4	S1970AM/RA3
<b>OLDSMOBILE - SEE GM FOR ADDITIONAL REFERENCES</b>				
Misc Models	1980	Ignition	P1098C-B50	
		Door/Trunk/GB	S1098D-B51	
	1979	Ignition/Door	P1098A-B48 (-P,-PC)	
		Trunk/GB	S1098B-B49 (-P,-PC)	
	1978	Ignition	P1098J-B46	
		Door/Trunk/GB	S1098K-B47	
	1977	Ignition	P1098E-B44 (-P,-PC)	
		Door/Trunk/GB	S1098H-B45 (-P,-PC)	
1976	Ignition	P1098C-B50		
	Door/Trunk/GB	S1098D-B51		
<b>PACKARD</b>				
All Models	1940-58	All	1098L-B3	—
Pantera	1972-74	Ignition	X86-FC7	X20/FC2
		Door/Trunk	FT37	—
			FT38	—
<b>PETERBILT</b>				
US Designed	1978-04	All	1098PB	H1098DB/B16
<b>PEUGEOT</b>				
505	1980-84	Ignition/Door	X116-RN24 (-P)	
		Trunk/GB	X89-KM9 63PX	
504	1979-83	Ignition/Door	X12-RE61F	
		Trunk/GB	63PX	
604	1978-83	Ignition/Door	NE34	
		Trunk/GB	X89-KM9	
	1977	Ignition/Door	X89-KM9	
		Trunk/GB	63PX	
Misc Models	1965-79	Ignition/Door	X12-RE61F	
			RE61XR	
		Trunk/GB	63PX	
			63P	
			X89-KM9	
<b>PLYMOUTH</b>				
Misc Models	1968-85	Ignition/Door	P1770U-Y152 (-PC)	
		GB	S1770U-Y149	
All Models	1964-75	See Dodge		
	1960-63	Ignition/Door	1706K	—
		Trunk/GB	1759P	—
	1959	Ignition/Door	X1199J	—
		Trunk/GB	D1759L	—
	1957-58	Ignition/Door	X1199J	—
		Trunk/GB	XO1199G	—
1940-56	See Chrysler			
<b>PONTIAC - SEE GM FOR ADDITIONAL REFERENCES</b>				
Misc Models	1980	Ignition	P1098C-B50	
		Door/Trunk/GB	S1098D-B51	
	1979	Ignition/Door	P1098A-B48 (-P,-PC)	
		Trunk/GB	S1098B-B49 (-P,-PC)	

MODEL	YEARS	LOCK APPLICATIONS	ILCO/EZ [PLASTIC]	SUBSTITUTES
Misc. Models con't	1978	Ignition	P1098J-B46	
		Door/Trunk/GB	S1098K-B47	
	1977	Ignition	P1098E-B44 (-P,-PC)	
		Door/Trunk/GB	S1098H-B45 (-P,-PC)	
	1976	Ignition	P1098C-B50	
Door/Trunk/GB		S1098D-B51		
<b>PORSCHE</b>				
928 w/alarm	1978-95	All	HF55-P	
928 w/o alarm	1978-95	All	HF52-P	
944, 924	1976-88	Ignition/Door/Trunk	X9-73VB (-P)	X88/PA8,X139
		GB	61VW	
			V61VW	
			U61VW	62VW, VO6
All Models	1970-76	All	PO7	—
			PO6	—
	1970-76	Valet	X32-PO6	—
	1967-69	Ignition/Door	KP1	—
	1963-66	Ignition/Door	64K	—
			DM4	—
Mid 60's	Transmission	DM2	—	
<b>RENAULT</b>				
R17 Gordini	1980	Ignition	X116-RN24 (-P)	
	1977-79	Ignition	X12-RE61F	
	1979-80	Door/Trunk	X85-NE36	
X92-RN25				
R5 (Le Car)	1980-83	Ignition	X116-RN24 (-P)	
	1976-79	Ignition	X12-RE61F	
		Door/Hatch	X61-NE40	
<b>ROLLS ROYCE</b>				
All Models	1970-81	All	X28-62HE	—
		Valet	63HD	—
<b>SAAB</b>				
900, 99	1974-93	All	X52-SAA1 (-P)	—
Most Models	1974-75	All	X52-SAA1	—
	1967-73	All	X31-SB8	—
<b>STERLING</b>				
Sterling, 3500S	1976-86	Ignition	X157-LF17	
		Door/Trunk	X86-FC7 (-P)	X20/FC2
<b>STUDEBAKER</b>				
All Models	1949-63	Ignition/Door	X1199AR	—
			1125H-H5	—
		Trunk/GB	O1122A-Y12	—
	1947-48	Ignition/Door	X1199AR	—
			1125H-H5	—
	Trunk/GB	O1122AR-Y14	—	
1940-46		Ignition/Door	X1199AR	—
	Trunk/GB		O1122AR-Y14	—
<b>SUBARU</b>				
All Models	1977-81	Ignition/Door	X6-62DT	
		Trunk/GB	X108-SR6	
	1970-76	All	X6-62DT	—
<b>TOYOTA</b>				
Corolla Sedan, Coupe	1978-82	All	T61C-T61C (-P)	X137/TR33
Corona	1972-82	All	X37-TR28 (-P)	X159/TR37
Celica Coupe, Conv.	1970-83	All	T61C-T61C (-P)	—
		Valet	T61D	—
Corolla Station Wagon, 2W	1970-87	All	TR25	—
Misc Models	1970-82	All	X159-TR37 (-P)	
			X137-TR33 (-P,-PC)	
			X212-TR46 (-P,-PC)	X151/TR39
			X146-B56	X137/TR33
	1969-75	All	T61C	X137/TR33
1969-75	All	Valet	T61D	—
		All	T61F	—
		Valet	T61E	—

# 12 TOYOTA - VOLVO

MODEL	YEARS	LOCK APPLICATIONS	ILCO/EZ [PLASTIC]	SUBSTITUTES
Misc. Models con't		All	TR25	—
		Valet	X45-TA21	X159/TR37
	1969-75	All	X37-TR28	—
		Valet	X46-TA27	—
Many Models	Pre 1969	Ignition/Door	TA1	—
			TA6	—
		Trunk/GB	TR18	—
Crown	Pre 1969	All	TA5	—
Land Cruiser	1973-82	All	T61C (-P)	X137/TR33
	1965-72	All	TA16	—
			TA11	—
			TA5	—
			TA12	—
			TA2	—
		TA4	—	
<b>TRIUMPH</b>				
Most Models	1970-81	Ignition	MG1	—
			FT6R	X1/MZ12
		Door/Trunk	62FS	—
			62FT	—
Spitfire	1974 only	Ignition	WB1	—
GT6, Spitfire, Stag, TR6	1970-81	Door/Trunk	62FS	—
			62FT	—
			MG1	—
Most Models	1960's	Various	62DG	—
			62DP	—
			62FS	—
			62FT	—
<b>VOLKSWAGEN</b>				
Beetle	1971-78	All except GB	VW71	—
	1966-70	All	V27	VW67
411, 412	1971-74	All	X9-73VB	X203/V37
Dasher	1980-81	Ignition/Door/Trunk	X9-73VB (-P)	
		GB	X53-V32	
	1974-79	Ignition/Door	X9-73VB	X203/V37
		Trunk/GB	X53-V32	—
Rabbit, GTI, Golf	1975-84	All except GB	X9-73VB	X203/V37
Scirocco	1975-83	All except GB	X9-73VB (-P)	
Bus	1971-79	All except GB	VW71A	—
	1966-70	All	VW67S	—
Glove Box (except Dasher)			61VW	—
			V61VW	—
			U61VW	—
			S62DW	—
<b>VOLVO</b>				
240 Series, DL, GL	1977-83	Ignition	X80-VL6 (-P)	
Most Models	1973-76	Door/Trunk/GB	X30-VO73S	
		Ignition	X29-VO73	—
	Door/Trunk/GB	X30-VO73S	—	
	1968-72	Ignition	V062	—
		Door/Trunk	62FS	—
			UN16	—



Kaba Ilco Corp.  
 400 Jeffreys Road • Rocky Mount, NC 27804  
 Phone 800.334.1381 • Fax 252.446.4702  
 www.kaba-ilco.com

Form # 2907/E/0507